# Jaw Reshaping Procedure

### Attaching the jaws

Apply Locktite 242 (blue-white) to the attaching bolts and then tighten them with a torque wrench.

For the tightening torque, see page 16.


# Centering

Check that the actuator is centered relative to its circumference. If not, center the actuator. (See page 15).

#### Air source

Attach the rotating union securely to the chuck. (See page 17.) Set the precision regulator into the circuit to make the air

pressure variable and perform piping,



## Setting the air pressure

Set the air pressure to the value used for the previous finishing.