


Procedure for Attaching the Actuator and Cylinder

1. Checking the attaching surface



2. Attaching and centering the cylinder



Note: For centering, use a plastic hammer.